




C by Romain Gauthier

Owner's Manual and Warranty

Winding	2
Time setting	3
Stop-seconds mechanism	4
Removal / insertion of the strap	6
Removal / insertion of the pin buckle	7
Water resistance, maintenance and service	8

Winding



C by Romain Gauthier is a manual winding timepiece. It is wound using the crown at 2 o'clock.

1. Ensure the crown is pressed in
2. Turn the crown in the direction of the arrow

Important: To prevent overwinding, there is an in-built block that the wearer will feel the crown block when the watch is fully wound. Once this feeling is reached, do not try to wind any further.

Time setting




The time is set on C by Romain Gauthier using the small crown on the caseband at 2 o'clock.


To set the time, gently pull out the crown and turn clockwise or anticlockwise to the correct time. When the correct time is set, push the crown back in towards the case.

Important: Do not pull the crown out if the watch is wet or in water.

Stop-seconds mechanism




Position of the snail cam when the watch is working.



Position of the snail cam during time setting.

The mechanism employs a snail cam that performs a double function: It touches and stops the balance wheel when the crown is pushed back in, the snail cam makes a turn, with its increasingly wide form giving the balance an impulse to help it start beating again.

Removal / insertion of the strap




Removal

1. Using your fingertip, pull the release button away from the case.
2. Slide the bracelet downward.

Insertion

Important: The strap can only be inserted from the back of the case.
Slide the strap in until it clicks into place.

Removal / insertion of the pin buckle



Removal

Important: Throughout the entire process, keep the pin (the small needle) securely in its slot within the buckle.

1. Slide the strap keepers inward.
2. Press the buckle and the pin together backwards as far as possible toward the underside of the strap.
3. Once fully rotated, the buckle and the pin can be released and removed by pulling the buckle upward.

Insertion

Follow the reverse order of the removal steps.
Note: Once fastened around the wrist, the buckle will not come loose from the strap.



Water resistance

Your C by Romain Gauthier is water resistant to a static 30 metres/100 ft. However, vigorous swimming and diving should be avoided as moisture may be forced past the water-resistant seals.

Maintenance

Your timepiece has taken years to design, months to create the components for it, weeks to finish by hand and regulate. With care, it will last many generations.

Before delivery, it has been checked and tested to the highest standards. For a description of these tests and for a list of our tips for looking after your timepiece, please visit: romaingauthier.com/owners.

Service

We recommend sending your timepiece back to Manufacture Romain Gauthier for service at least once every three years. Your nearest authorised Romain Gauthier retailer can help you to do this. You can also email contact@romaingauthier.com.

A service sees your timepiece returned to the expert Romain Gauthier watchmaker who originally assembled and regulated it, ensuring continuity and quality. For full details of what a service entails, please visit romaingauthier.com/owners.

When returning your watch for service, to ensure safe shipping we suggest putting the timepiece in the travel pouch that came with the watch, then placing this travel pouch in a sizeable cardboard box with protective polystyrene filling.